



Acer Travelmate C100 Series Teardown

Teardown of a old Acer Travelmate C100 Series.

Written By: Hayden Norton



INTRODUCTION

This is a tear down of an Acer Travelmate C100 Series notebook.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [6-in-1 Screwdriver](#) (1)
 - [Flathead 3/32" or 2.5 mm Screwdriver](#) (1)
-

Step 1 — Acer Travelmate C100 Series Teardown



- First, we remove the screws from the bottom of the notebook, so we can access the internal components.
- The battery is is a 14.8V 1800mAH Lithium Ion battery.

Step 2



- Remove Keyboard and Screen. these prevent you from accessing the internal components.
- Keyboard info. The keyboard is a basic keyboard without number keypad. Model # NSK-A5001

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 04:04:39 PM.